



Solenoid vents and allows diaphragm to open as pressure now unequal and spring alone unable to maintain seal.

Solenoid shut and equal pressures plus spring maintain seal.

Normal running Condition
Contaminated air drawn thro
cartridge and dust collects
on outside of media.

Cleaning Sequence.
Pulse induces backflow and
shock dislodges dust from
outside of cartridge.

Basic Principles of Reverse Jet/Pulse Cleaning.

DUSTAIR LIMITED
 ENGINEERS IN DUST AND FUME CONTROL
 UNIT 13, PEDMORE IND. ESTATE, PEDMORE ROAD, BRIERLEY HILL, WEST MID'S, DY5 1TJ
 TELEPHONE +44(0)1384 76662 / 77716, FAX +44(0)1384 77227.
 E-MAIL: SALES@DUSTAIR.CO.UK WEB SITE: WWW.DUSTAIR.CO.UK